ΕN

Product description

Switch mode power supply unit (PSU) UP413 is intended to supply devices, required increased reliability of supply voltage for back-up function implementation. Enable work of 2 or more PSU UP413 in parallel connection.

The unit is intended for indoor use only.

Safety instructions

The PSU is powered from the mains 230 V~. This voltage is dangerous to life.

Any repairs must be done by a qualified personnel.

PSU is double isolated from the mains 230 V~.

Do not remove the cover without disconnecting PSU from the mains.

Do not plug the PSU into the mains supply if the power cord or plug is damaged.

To disconnect the PSU from the mains completely, disconnect plug from the mains socket.

The mains socket must be easily accessible.

PSU shall not be exposed to dripping or splashing water and no objects filled with liquids, such as vases, shall be placed on it.

Avoid placing PSU next to central heating components and in areas of high humidity.

No naked flame sources, such as lighted candles, should be placed on PSU.

If the PSU has been kept in cold conditions for a long time, keep it in a warm room no less than 2 hours before plugging into the mains.

The ventilation should not be impeded by covering the ventilation openings with items, such as newspapers, table-cloths, curtains.

Mount the PSU in vertical position.

From top, front and bottom of installed PSU must be at least 10 cm free space.

External view




Figure 1. External view of PSU UP413

- 1 mains connector
- 2 STATUS indicator of the module's status (at normal conditions glows green, at overload or overtemperature glows red)
- 3 power distribution bus connectors
- 4 12 V output (screw terminal)
- 5 functional grounding clamp

Installation

When outputs of UP413 are working in parallel it is recommended to connect PS units to different lines of the mains or one to the line directly, another via uninterruptable power source (UPS). Disconnected from the mains one PSU does not disturb parallel working PSU.

Warning!

- Maximal output current of parallel connected PS units can not exeed output current of one PSU.
- Connecting or disconnecting powering of modules must be done when PSU is disconnected from the mains.
- Connection of other model of PSU in parallel with UP413 is not allowed.

Technical characteristics


Supply voltage limit values	187-250 V~ 50/60 Hz
Output voltage	12 V ± 0.5 V
Power consumption	65 W max.
Output current	0-4.5 A short circuit and overload protected
Ripple, 100 Hz	< 10 mVpp
Noise	< 50 mVpp
Temperature range	050°C
Dimensions/Weight (packed)	198x107.5x36 mm/0.97 kg

MOUNTING

The module or mounting bracket must be fixed with steel screws Ø 3.5-4 mm. The screws are not included in a package.

Mounting on a wall by screws

Mounting on a bracket (supplied)



Perpendicular to the wall

Figure 2. Mounting of PSU

Parallel to the wall

Mounting on DIN rail




Figure 4. Mounting from DIN rail




Figure 5. Mounting or removing to/from DIN rail of plastic spacers (supplied).




Figure 6. System with 2 PS units UP413 in parallel connection

